

eGPS main screen while GNSS enabled



Current configuration

Receiver status

Disabled
 Initialize
 Ready

Battery
in %

52 > 50
50 > 20
2 <= 20

Power

G: GPS-Receiver
M: Modem
B: Bluetooth

off
 on

Current position

GPS Satellite

x / y: x of y Satellite uses for solution

0/0 no Satellite
0/7 not in solution
7/8 in solution
6/8 with correction

GLONASS Satellite

x / y: x of y Satellite uses for solution

0/0 no Satellite
0/7 not in solution
7/8 in solution
6/8 with correction

Solution type

A: Autonomous
D: DGPS
F: Float
R: RTK (Fix)

A without correction
D with correction

eGPS Skyplot View (click Menu / Skyplot)

